

INFORMATION SHEET

GENERAL INFORMATION

| | |
|------------|---|
| Provider | Fripac-Medis GmbH Frankenbergstraße 37 71579 Spiegelberg Germany Tel. +49 (7194) 95000 Fax +49 (7194) 950010 eMail: nfo@fripac-medis.de |
| Trade name | Fripac Mondial Ion - Hairdryer |
| category | Hairdryer Electrical items |
| Updated | March 28, 2025 |

TECHNICAL DATA

| | |
|---------------------|------------------------------------|
| hair clipper | |
| drive | DC motor (collector motor), 1900 W |
| Operating voltage | 220-240 V - 50 / 60 Hz |
| Operating mode | network |
| Cable length | 2.8 m |
| Blowpipe diameter | 45 mm |
| Weight | 370 g |

Safety instructions

To avoid damage due to improper use, please read and carefully store the operating instructions. A copy of the operating instructions is available upon request by calling +49 (7194) 95000, by emailing info@fripac-medis.de, or visiting www.fripac-medis.de.

The device is to be used only for drying hair. Any other use is prohibited.

The device is not a toy!

Make sure that the voltage indicated on the device's rating plate matches the mains voltage.

The device should never be used in the bathtub, shower, over a sink filled with water, or with wet hands. The device should also not be used near water contained in bathtubs, sinks, or other containers, and should never be immersed in water.

If the hairdryer is used in a bathroom, always unplug it after use, as proximity to water poses a hazard, even when the device is turned off. For additional protection, we recommend installing a residual current device (RCD) with a rated tripping current of no more than 30 mA in the bathroom circuit. Consult your electrician for advice.

Always turn off the device after use. Always unplug the device when not in use or when cleaning.

This appliance can be used by young people aged 8 years and over and persons with reduced physical, sensory, or mental capabilities, or lack of experience and/or knowledge, provided they are supervised or have been instructed in how to use the appliance safely and understand the hazards involved. Protect your children: We advise against using this appliance by children under 8 years of age, as they often lack the necessary motor and mental skills to use it correctly. They also lack understanding of the hazards associated with the appliance, such as accidental burns from the hot surface.

Children should not play with the device. Cleaning and maintenance should not be performed by children without supervision.

Do not operate the device if the cord or plug is damaged, or if the device itself is damaged. In the event of a defect and/or malfunction, immediately turn off the device and unplug it. If the power cord, plug, or device is damaged, never attempt to repair the device yourself, as improper repairs could pose a significant risk to the user. Contact your authorized dealer.

Unplug the power cord before cleaning or servicing the device. See also Care and Maintenance.

When unplugging the device, never pull on the power cord or the device itself.

Do not carry the hairdryer by holding the power cord.

The A-weighted emission sound pressure level is below 70 dB(A).

Disposal

This electrical/electronic product must not be mixed with normal household waste. For proper treatment, recovery, and recycling, please take these products to the appropriate collection points, where they will be accepted free of charge. In some countries, it may also be possible to return these products to your local retailer when purchasing a new product. Proper disposal of this product will help protect the environment and prevent potential harmful effects on people and the environment that could arise from inappropriate waste handling. For more information about your nearest collection point, please contact your local council.

In accordance with state law, penalties may be imposed for improper disposal of this type of waste.